



Southco Customer Service and Technical Support

Americas Global Headquarters
Concordville, PA · USA
Tel: (1) 610 459 4000

Europe Headquarters
Worcester · UK
Tel: (44) (0) 1905 346722

Asia Headquarters
Hong Kong · China
Tel: (852) 3127 1503

Brazil Tel: (55 11) 4617 9988
Canada Tel: (1) 905 855 0309
Mexico Tel: (1) 877 821 0666
USA Tel: (1) 610 459 4000

Austria Tel: 0800 281 831
France Tel: 0800 912 756
Germany Tel: 0800 1800 380
Italy Tel: 800 780 953
Spain Tel: 900 968917
Sweden Tel: 020 790 366
UK & NI Tel: 0845 117 922

Australia Tel: (61) 03 9330 5000
China Tel: (800) 820 0272
Tel: (400) 880 8900
India Tel: (91) (21) 3867 0538
Japan Tel: (81) 6 6466 1200
Korea Tel: 0505 777 1234
Malaysia Tel: 1800 801 119
Singapore Tel: 800 18 11016
Taiwan Tel: 0800 558 015



Visit www.southco.com for all your Access Hardware needs

Download CAD Files

Validate your product selection in your own CAD design with our industry standard CAD models.

Request Samples

Take the next step by ordering product samples to test in your design.

Check Stock

Confirm product inventory and lead time with our global support team.

Order Print Catalog

Request your FREE Southco Handbook to access over 500 full color pages with detailed specifications, part numbers and performance details.

Access Online Catalog

Quickly narrow your selection, bookmark content and share it with our full text search feature.

User Account

Create and share projects with others, save CAD files, compare products, and more.

Compliance Statements

Verify compliance statements for products, materials and manufacturing processes.

Online Chat

Need assistance? Chat with our global customer service team online for on demand support.

WORLDWIDE MANUFACTURING AND STOCKING LOCATIONS

Concordville, Pennsylvania, USA · Honeoye Falls, New York, USA · Philadelphia, Pennsylvania, USA · Warminster, Pennsylvania, USA · Chihuahua, Mexico · Tecate, Mexico · São Paulo, Brazil · Farnham, UK · Worcester, UK · Hong Kong, China · Shenzhen, China · Shanghai, China · Seoul, Korea · Melbourne, Australia · Pune, India · Osaka, Japan

BLUETOOTH[®] Controller





Southco's **BLUETOOTH®** Controller Monitor & Control Access to Equipment – Wirelessly

Southco's EA-BT **BLUETOOTH®** Controller provides full remote control and monitoring of electronic locks without the need to wire into a network.

Southco's **BLUETOOTH®** Controller allows **BLUETOOTH®** wireless technology enabled devices, such as smartphones and tablets to be used as a key.

Southco's BLUETOOTH® Controller offers a streamlined solution for the remote management of user credentials.

Cloud-based Key Management Service

VIZpin provides a secure, web based platform for remote management of user access to Southco's **BLUETOOTH®** Controller. Time based virtual keys can be sent wirelessly to a smartphone application via VIZpin cloud based web portal. The **BLUETOOTH®** Controller can control up to 3 connected locks independently.



System Benefits

- **Audit Trail**
Compile reports for compliance and reporting purposes
- **Authorize/Revoke Access Remotely**
Physical access to the **BLUETOOTH®** controller is not required
- **Time Based Credentials**
Grant access to users for a specific time frame
- **Cloud-based Software**
No local software installation is required and the portal can be accessed anywhere in the world with an internet browser
- **Security**
The highest level of security through a proprietary technology with multilayer encryption

VIZpin is an authorized trademark of ECKEY® Corporation.
The **BLUETOOTH** word mark and logo are registered trademarks of Bluetooth SIG, Inc and are used under license.

VIZpin® Set Up

Virtual keys can easily be assigned through VIZpin's secure web portal. The admin can remotely add or delete electronic keys, in real time, granting access to users for a specified period of time.




How it works:

1. The admin sets up an account on VIZpin's secured web portal
2. Users download the VIZpin® mobile app (for iOS® or Android® devices)
3. Time based VIZpin® virtual keys are pushed to registered mobile devices, such as a smartphone or tablet
4. **BLUETOOTH®** controlled devices authorized for access are displayed on the user's mobile application
5. The user simply selects the lock icon to send the encrypted wireless unlock signal to the controller
6. When access is revoked, via the web portal, a command is sent to the mobile application to revoke authorization
7. Unlock attempts are tracked and sent via the cloud to VIZpin's web portal for remote monitoring



User Access

VIZpin allows users to receive virtual keys through a downloaded app on their smartphone. The user simply opens the app to see any virtual keys they have received, along with the associated locked equipment location, description and period of access time.

How to Access Virtual Keys:



Access details by pressing the info button



Download the VIZpin® App



Android® devices



iOS® devices

- User logs into application
- A list of virtual keys are displayed
- Virtual keys that are in range of a **BLUETOOTH®** Controller are highlighted

- User selects "info" for access details including:
 - Physical address of equipment
 - Access time window
 - Key expiration date

- User presses "key" icon for access
- **BLUETOOTH®** controller verifies virtual key then sends signal to unlock the connected lock
- Transaction is captured and pushed to VIZpin® portal for audit trail

iOS is a registered trademark of Apple, Inc.
ANDROID is a registered trademark of Google, Inc.

For use with Southco's Electronic Locking Solutions



H3-EM



EM-05



R4-EM 8



R4-EM 9



EM-10



R4-EM 7

southco[®]
CONNECT · CREATE · INNOVATE

www.southco.com